




Electra-Dyne Co., Inc.  
P.O. Box 1344  
Plymouth, MA 02362  
tel: (508) 746-3270  
fax: (508) 747-4017  
mail@electra-dyne.com  
www.electra-dyne.com

## Box Hauler Wiring Diagram



To make the sheaves turn in the opposite direction,  
simply reverse the polarity.